

Example: Mixed-order HHO Elasticity

```
1 using Gridap
2 using Gridap.Geometry, Gridap.FESpaces
3 using Gridap.MultiField, Gridap.CellData
4 using Gridap.ReferenceFES, Gridap.TensorValues
5 using Gridap.Arrays
6
7 using Gridap.Fields: skew_symmetric_gradient
8
9  $\mu, \lambda = 1.0, 1.0$ 
10 I2 = one(SymTensorValue{2,Float64})
11 I4 = one(SymFourthOrderTensorValue{2,Float64})
12 C =  $\lambda * I2 \otimes I2 + \mu * I4$  # Isotropic tensor
13
14 u(x) = Point(sin(2 $\pi$ *x[1]),cos(2 $\pi$ *x[2]))
15 g(x) = Co( $\epsilon(u)(x)$ )
16 f(x) = -( $\nabla \cdot g$ )(x)
17
18 model = voronoi_mesh((0,1,0,1),(6,6))
19 D = num_cell_dims(model)
20  $\Omega$  = Triangulation(ReferenceFE{2}, model)
21  $\Gamma$  = Triangulation(ReferenceFE{1}, model)
22
23 order = 2
24 V = PolytopalFESpace(
25    $\Omega$ , VectorValue{D,Float64}, order+1
26 )
27 M = PolytopalFESpace(
28    $\Gamma$ , VectorValue{D,Float64}, order;
29   dirichlet_tags="boundary"
30 )
31 N = TrialFESpace(M,u)
32
33 ptopo = PatchTopology(model)
34  $\Omega_p$  = PatchTriangulation(model,ptopo)
35  $\Gamma_p$  = PatchBoundaryTriangulation(model,ptopo)
36
37 qdegree = 2*(order+1)
38 d $\Omega_p$  = Measure( $\Omega_p$ ,qdegree)
39 d $\Gamma_p$  = Measure( $\Gamma_p$ ,qdegree)
40
41 style = BlockMultiFieldStyle(2,(1,1))
42 X = MultiFieldFESpace([V, N];style=style)
43
44 Y = MultiFieldFESpace([V, M];style=style)
45
46 P $\Gamma$  = projection_operator(M,  $\Gamma_p$ , d $\Gamma_p$ )
47 R = reconstruction_operator_sym( $\Omega$ ,ptopo,X,order)
48 G = gradient_operator( $\Omega$ ,ptopo,X,order)
49 hT = CellField(sqrt.(get_cell_measure( $\Omega_p$ ))),  $\Omega_p$ )
50
51 function a(u,v)
52   Gu_ $\Omega$ , Gu_ $\Gamma$  = G(u)
53   Gv_ $\Omega$ , Gv_ $\Gamma$  = G(v)
54   return  $\int ((Gu_ $\Omega$ +Gu_ $\Gamma$ )  $\otimes$  C  $\otimes$  (Gv_ $\Omega$ +Gv_ $\Gamma$ ))d $\Omega_p$$ 
55 end
56
57 function s(u,v)
58   S $\Gamma$ ((uT, uF)) = P $\Gamma$ (uT) - uF
59   return  $\int ((1/hT) * (S $\Gamma$ (u)·S $\Gamma$ (v)))d $\Gamma_p$$ 
60 end
61
62 l((v $\Omega$ ,v $\Gamma$ )) =  $\int (f \cdot v $\Omega$ )d $\Omega_p$$ 
63
64 function weakform(ptopo,assem,X,Y)
65   Xp = FESpaces.PatchFESpace(X,ptopo)
66   u, v = get_trial_fe_basis(X), get_fe_basis(Y)
67   data = collect_and_merge_cell_matrix_and_vector(
68     assem,
69     (Xp, Xp, a(u,v), DomainContribution(), zero(Xp)),
70     (X, Y, s(u,v), l(v), zero(X))
71   )
72   return assemble_matrix_and_vector(assem,data)
73 end
74
75 assem = PatchAssembler(ptopo,X,Y)
76 op = StaticCondensationOperator(
77   X,assem,weakform(ptopo,assem,X,Y)
78 )
79 xh = solve(op)
80 uT, uF = xh
81 Ru = R(xh)
82
83 d $\Omega$  = Measure( $\Omega$ ,qdegree)
84 l2_err = sqrt(sum( $\int ((Ru - u) \cdot (Ru - u)) * d\Omega$ )))
```