

InterfaceHouseKeeping message structure

DataItem1 0 1		DataItem2 2 3		DataItem3 4 5		DataItem4 6 7	
DataItem5 8 9		DataItem6 10 11		DataItem7 12 13		DataItem8 14 15	

Legend: **DataItem1:** Nominal transceiver circuit voltage (double). **DataItem2:** Redundant transceiver circuit voltage (double). **DataItem3:** Internal power supply measured with nominal ADC (double). **DataItem4:** Internal power supply measured with redundant ADC (double). **DataItem5:** Main board PCB temperature measured by sensor 1 (double). **DataItem6:** Main board PCB temperature measured by sensor 2 (double). **DataItem7:** Sun sensor board PCB temperature from sensor 3 (double). **DataItem8:** Sun sensor board PCB temperature from sensor 4 (double).

InterfaceStatus message structure

Data Item1	Data Item2	Data Item3	Data Item4
0	1	2	3

Legend: **DataItem1:** Bit 0 to 2, information about last reset. Bit 3 indicates if ADCS is ready. Bit 4 indicates an OBC communication error. Bit 5 indicates a communication error with the connected units (binary). **DataItem2:** Each bit indicates the unit in error (Gyroscope, Reaction Wheel, Magnetorquer, Magnetometer, Sun Sensor) (binary). **DataItem3:** Watchdog reset counter incremented at every reset (integer). **DataItem4:** Device reset counter (integer).