Station (STA)

Access Point (AP)

CSI Data Collection

CSI Data Collection

Thresholds Estimation Using WC A_{STA}

1- Send L CSI samples, and Wavelet Transform settings to AP.

2- Receive α, β, time shift.

L CSI samples

Thresholds Estimation Using WC A_{AP}

1- Receive CSI Samples from STA.

2- Compute WC between AP & STA CSI.

3- Find N_F: the number of frequency components in WC.

Thresholds Estimation:

1- Initialize α = max(WC), β = L.

2- Find frequency components $\{F_{rec}\}$ whose WC >= α and last for duration >= β using AP's and STA's CSI.

3- If $|F_{rec}| < 0.5\ N_F$:
Update α = α - 0.05, β = L - L/3.
Start at step **2**.

4- Reconstruct AP's CSI by computing the IWT of the CSI's wavelet coefficients in the range [min(F_{rec}), max(F_{rec})].

5- Reconstruct STA's CSI by computing the IWT of the CSI's wavelet coefficients in the range [min(F_{rec}), max(F_{rec})].

6- Estimate time shift between the reconstructed CSI.

7- Send α, β, and time shift to STA.

α, β, time shift

WT CSI Reconstruction & Synchronization B_{STA}

Using new CSI samples, α, β, and time shift:

1- Compute WT of CSI.

2- Find N_F : the number of frequency components in WT.

3- Find frequency components $\{F_{rec}\}$ whose WC >= α for time duration >= β.

4- If $|F_{rec}| < 0.5\ N_F$:
Start at step A_{STA}.

5- Reconstruct CSI using IWT and frequencies in the range [min(F_{rec}), max(F_{rec})].

6- Use time shift to discard out of sync samples.

7- If thresholds update is received:
Start at step A_{STA}.

WT CSI Reconstruction & Synchronization B_{AP}

Using new CSI samples, α, β, and time shift:

1- Compute WT of CSI.

2- Find N_F : the number of frequency components in WT.

3- Find frequency components $\{F_{rec}\}$ whose WC >= α for time duration >= β.

4- If $|F_{rec}| < 0.5\ N_F$:
Request thresholds update.
Start at step A_{AP}.

5- Reconstruct CSI using IWT and frequencies in the range [min(F_{rec}), max(F_{rec})].

6- Use time shift to discard out of sync samples.

Thresholds update requests