

Query1: You are a hardware security engineer expert in security analysis of the RTL designs. You are going to help in developing an asset-centric threat modeling of an SoC.

First you need to identify the assets from a buggy RTL code. Here is the generic asset definition you need to look for in this buggy RTL code-

```
// module dma {  
...  
endmodule
```

Query2: Now I will provide you a threat model database. This threat model database is generated from CWEs, where for each CWE there is a threat model. You need to find out the applicable CWEs from the threat model database which are pruned to affect these sensitive assets that you listed.

Provided: Threat Model Database

- Generic Asset Definition- Runtime Integrity & State assets:**
- 1. These assets relate to the ongoing, correct, and secure operation of the SoC after it has successfully booted. Their purpose is to maintain and prove the device's trustworthiness during operation.
 - 2. Device Integrity and Operation: The overall goal of ensuring the system runs as intended without crashing or being compromised.
 - 3. Hardware State and Logic Integrity: The correctness of internal hardware components, like Finite State Machines, that control secure operations.
 - 4. Keywords may include- "state_*" "default_*", "measurement_*

A) DMA control / FSM (hardware state & logic integrity)

LLM's Response1

1) name: dma_ctrl_fsm
signals: [dma_ctrl_reg, dma_ctrl_new, dma_ctrl_en]
role: "Drives the whole DMA lifecycle"
why_sensitive: "Corrupting/forcing state can skip PMP checks, double-execute, or stall system."
2) name: dma_phase_vector
signals: [valid_reg, valid_new, valid_en, valid_o]
role: "Runtime progress/attestation of what the DMA is doing right now."
why_sensitive: "Downstream logic trusts it; spoofing can hide illegal transfers."

B) Security enforcement state (PMP gate for DMA)
.....
D) Handshake / abort control (system-wide operation integrity)
.....

Most applicable CWE threat models from your database-

LLM's Response2

CWE-1257: Improper Access Control Applied to Mirrored or Aliased Memory Regions
CWE-1245: Improper Finite State Machines (FSMs) in Hardware Logic
CWE-1221: Incorrect Register Defaults or Module Parameters
.....

*Ordering does not matter