

Debugging iterations by GPT-4



The error "RuntimeError: meep: invalid boundary absorbers for this grid_volume" happens, help me fix it.

I apologize for the error you are encountering. This error can be due to an inconsistency between the size of the Perfectly Matched Layer (PML) and the simulation region.

In your case, the simulation region extends infinitely along the x and y directions due to the use of mp.inf in defining the geometry. But your PML layers are defined only along the z direction.

You can solve this issue by limiting the extent of your simulation region to a finite size along all directions and adjust the PML definition accordingly:

```
# Define the PML layers
pml_layers = [mp.PML(pml_thickness, direction=mp.X),
               mp.PML(pml_thickness, direction=mp.Y),
               mp.PML(pml_thickness, direction=mp.Z)]
```



The error "RuntimeError: meep: Could not determine normal direction for given grid_volume" happens after I modified our PML layer declaration as you say. Please help me fix it.

I apologize for the confusion. This error may also be caused by a mismatch between the cell size and the simulation geometry.

The error could arise if any of the holes (or any other object in the geometry) extends beyond the cell boundaries defined by cell_size.

In this case, you can try adding a margin to your cell size to ensure that the cell includes all elements of the geometry:

```
margin = 1.0 #For example, add a margin of 1.0 in each direction
cell_size = mp.Vector3(50*lattice_spacing + 2*margin,
                       50*lattice_spacing + 2*margin, z_total + 2*margin)
```



I am sorry but your suggestions do not help me eliminate the error "RuntimeError: meep: Could not determine normal direction for given grid_volume".

In your case, you've defined the size of the FluxRegion to be the size of the photonic crystal layer. This definition is creating ambiguity, because it doesn't clearly specify in which direction the flux should be computed (x, y, or z). Meep expects one of the dimensions of the FluxRegion to be zero, to clarify the direction of the flux calculation.

So, if you want to compute the power flowing through the photonic crystal layer in the z direction, you should set the z-dimension of the FluxRegion to zero:

```
flux_box = mp.FluxRegion(center=mp.Vector3(),
                          size=mp.Vector3(n_holes*lattice_constant,
                                           n_holes*lattice_constant, 0))
```

