

Authors	Reference(s)	Coalescence	Regime	Local void fraction	Bubble size measurements	Local gas/bubble velocity
Yao B.P., Zheng C., Gashe H.E. and Hofmann H.	Chemical Engineering and Processing, 1991	Weak coalescence. The authors indicate that some coalescence is present. Yet the data provided indicate a limited increase of the bubble size : the latter increases by about 1mm between H/D=2.6 and H/D=12	Transition not indicated. Possibly for $V_{sg} \approx 4\text{-}5\text{cm/s}$	Conductivity probe	Five-point conductivity probe. Signal processing not detailed	Bubble velocity : Ultrasound Doppler probe. Signal processing not detailed Gas flux velocity : from five-point conductivity probe. Velocity weighted by the gas residence time
Camarasa E., Vial C., Poncin S., Wild G., Midoux N. and Bouillard J.	Chemical Engineering and Processing, 1999	Unclear for water No undisputable evidence as the bubble size at injection is not given. Possibly some coalescence in water according to bubble size distributions that extend from 1 up to 8mm at $V_{sg} \approx 8\text{cm/s}$. No or weak coalescence for water + pentanol	Transition with the multiple orifices injector at $V_{sg} \approx 4\text{ cm/s}$ for water and at $V_{sg} \approx 5\text{-}6\text{cm/s}$ for water + pentanol. "Pure" heterogeneous regime beyond $V_{sg} \approx 14\text{cm/s}$	Single optical fiber probe	Direct imaging (photography) + DGD (dynamic gas disengagement) technique.	Dynamic gas disengagement technique
Chen W., Tsutsumi A., Otawara K. and Shigaki Y.	The Canadian Journal of Chemical Engineering, 2003	Unclear No clear quantitative information on coalescence. Possibly weak in the D=0.2 and 0.4m columns and significant in the D=0.8m column in which much wider chord lengths distributions were observed. Yet, the enhanced coalescence in the D=0.8m column may result from the strong flow asymmetry	Transition at $V_{sg} \approx 5\text{cm/s}$	Single tip cleaved optical probe	Chords as detected by the probe. No statistics provided	Velocity determined from Doppler signals collected by a cleaved optical probe. Signal processing not detailed. Successive use of upward directed and downward directed probe
Chaumat H., Billet A.-M. and Delmas H. Chaumat H., Billet-Duquenne A.-M., Augier F., Mathieu C. and Delmas H.	Int. J. Chemical Reactor Engineering, 2006 Experimental Thermal Fluid Sci. 2007	Unclear Coalescence may be present but no clear evidence. NB The bubbles detected at low altitude (0.25m) are larger than at higher altitude (0.65m) - see their Fig. 9 and 10: this may be due to break-up at injection	Transition occurs over the interval $2 \leq V_{sg} \leq 6.4\text{cm/s}$ for the injector with 1mm I.D. orifices, and over the interval $6.4\text{cm/s} \leq V_{sg} \leq 16\text{ cm/s}$ for the injector with 0.5mm I.D. orifices	Optical probe	Mean Sauter diameter deduced from the most probable bubble velocity and from the mean detection frequency	Double optical probe. Vertical distance between tips 1.7mm. Evaluation of the most probable bubble velocity
Xue J., M. Al-Dahhan, M.P. Dudukovic and R.F. Mudde	AIChE J., 2008	Significant coalescence. There is no data on the evolution of the bubble size along a vertical at fixed V_{sg} . Yet, the mean bubble chord neatly increases from 2-3mm in the homogeneous regime ($V_{sg}=2\text{cm/s}$) up to 6-10mm in the heterogeneous regime. There is also a significant increase in the chord standard deviation from $\approx 1\text{mm}$ to 10mm as V_{sg} increases. The bubble chord distribution remains the same for $V_{sg} \geq 30\text{cm/s}$, i.e. for pure heterogeneous conditions	Heterogeneous regime for the data collected at V_{sg} from 8cm/s to 60cm/s	Optical probe	Chords as detected by the multiple tips probe.	Four tips optical probe (axial distance 2 mm, radial distance 0.6mm)
Maximiano Raimundo P., Maximiano Raimundo P., Cartellier A., Beneventi D., Forret A. and Augier F.	PhD thesis 2015 Chem. Eng. Sci. 2019	No or weak coalescence according to the axial evolution of chord distributions in columns 0.15 ; 0.4 and 1 m in diameter	The homogeneous region ends at $V_{sg} \approx 4\text{cm/s}$. Pure heterogeneous regime observed for V_{sg} above $\approx 4\text{-}5\text{cm/s}$ except in the D=0.4m column where the transition region exhibits a peak in a void fraction versus V_{sg} plot, and where pure heterogeneous flows are observed for $V_{sg} \geq 10\text{cm/s}$.	Single fiber optical probe	Direct imaging technique + Correlation technique using two parallel probes / Single fiber optical probe	Velocity deduced from the dewetting time of an optical probe
Guan X. and Yang N.	Chemical Engineering Research and Design, 2017	No or weak coalescence (see their fig.13)	Transition around 5cm/s. Pure heterogeneous regime	Dual tip conductivity probe	Reconstructed from the double phase detection probe assuming a one-to-one relationship between size and eccentricity	Horizontal double conductivity probe. Distance between probe tips 1.5mm. Holder tubes 4mm O.D.