

Droplets on a Tilted Plate

M. Musterd, V. van Steijn, C.R. Kleijn and M.T. Kreutzer

Faculty of Applied Sciences,
Delft University of Technology, Delft, The Netherlands

November 27, 2021

Abstract

In this short paper we present a fluid dynamics video of the deformation of droplets when tilted on a motorized stage. This is a submission to the 2013 Gallery of Fluid Motion which is part of the 66th annual meeting of APS-DFD. The video shows how differently placed droplets on the same surface will show a universal behaviour when tilted back and forth.

1 Explanation and background of the video

We deposit droplets in various initial states which are subsequently tilted to near roll-off and then tilted back to horizontal. We study the deformation from initial to final state. Droplets with different initial contact angles are achieved by depositing droplets of larger or smaller volume and emptying/filling these on the surface to the desired 50 μL . Emptying results in contact angles closer to the receding angle, whereas filling results in contact angles closer to the advancing angle. If necessary, vibration can be used to achieve the most stable contact angle on the given surface, which will be roughly half-way the advancing and receding angles.

When tilted the front or rear contact point of the droplet will move first, depending on the initial state of the droplet. When tilted close to the roll-off angle and then returned to horizontal the base length of all droplets, regardless of their initial shape, will have become similar.

2 Experimental setup and conditions

All droplets are distilled water of MilliQ quality and have a volume of 50 μL . The surface consists of a 4-inch silicon wafer coated with a 10 micron layer of PDMS (Sylgard) in 5:1 ratio with the curing agent. This results in advancing and receding contact angles of 119 and 92 degrees respectively. The substrate is tilted at a rate of $0.25^\circ/\text{s}$.